
LEGEND FLEET SOLUTIONS


TRANSIT 148" HIGH ROOF WALL LINERS INSTALLATION INSTRUCTIONS

NOTES:


- 1. Before commencing, remove all wall liners and "D" Rings already installed in the vehicle.
- 2. Consult layout PDF and compare vehicle layout allocated Legend.
- 3. Prepare hardware shown below and have them ready for installation.
- 4. Wall liners will be installed in the order shown in the instructions.
- 5. A drill with a Phillips driver is required to install (**C**) #8 Screws, shown below.
- 6. Reinstall all "D" Rings once the wall liner kit installation is completed.





TRANSIT 148" HIGH ROOF WALL LINERS




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	744-114-2613.HR	GREY REAR PANEL DRIVER SIDE TRANSIT 148'' HR	1
2	744-114-2613.HR	GREY FRONT PANEL DRIVER SIDE TRANSIT 148 HR	1
3	744-114-2613.HR	GREY REAR PANEL PASSENGER SIDE TRANSIT 148'' HR	1
4	744-114-2613.HR	GREY REAR UPPER DRIVER SIDE PANEL TRANSIT 148 HR	1
5	744-114-2613.HR	GREY FRONT UPPER DRIVER SIDE PANEL TRANSIT 148 HR	1
6	744-114-2613.HR	GREY FRONT UPPER PASSENGER SIDE PANEL TRANSIT 148 HR	1
7	RETAINER	RETAINER- BLACK NYLON	127
8	745-114-2613.HR	GREY CEILING FRONT PANEL TRANSIT 148" HR	1
9	745-114-2613.HR	GREY CEILING BACK PANEL TRANSIT 148" HR	1
10	SCREW	SCREW - PHIL. PAN HD #8X.75 SELF DRILLING	70
11	743-114-2613.HR	GREY REAR UPPER DOOR PANEL PASSENGER SIDE TRANSIT 148 HR	21
12	743-114-2613.HR	GREY REAR UPPER DOOR PANEL DRIVER SIDE TRANSIT 148 HR	1
13	SCREW CAP	SCREW CAP	34
14	742-xxx-6641	FLOOR - TRANSIT 148''	1
15	708-151-1011	FLOOR REAR SILL- TRANSIT	1
16	706-151-1011	FLOOR SLIDING DOOR SILL 3 - TRANSIT	1
17	706-151-1011	FLOOR SLIDING SILL 1- TRANSIT	1
18	709-151-1011	FLOOR SLIDING DOOR SILL 2 - TRANSIT	1
19	RETAINER	RETAINER- BLACK NYLON 31163211	12
20	743-114-2613.HR	GREY SIDE DOOR TOP PANEL TRANSIT 148'' HR	1
21	743-114-2613.HR	GREY SIDE DOOR BOTTOM PANEL TRANSIT 148 HR	1
22	747-151-1010.HR	CEILING SILL 2 TRANSIT 1 48'' HR	2
23	747-151-1010.HR	CEILING SILL 1 TRANSIT 1 48" HR	2
24	747-151-1010.HR	CEILING SILL JOINER PLATE	2











Ceiling Liner Installation







<u>7</u>: Assemble Item 22 and item 23 together with the Item 7, Sill Joining Plate (SHOWN BELOW), with hardware (C) in the holes provided.

- Install the Sill assemblies on the Driver side as well as on the Passenger side using hardware (C) in the holes provided on the Sills.
- First, Install the Sill assembly with hardware (C) on the wall, afterwards install hardware (C) only on the roof cross bows aligned with the retainers holding the ceiling panels.

ITEM 24 SILL JOINING PLATE







Floor and Floor Sill Installation

