LEGEND FLEET SOLUTIONS

TRANSIT 148" LOW ROOF WALL LINER

INSTALLATION INSTRUCTIONS



NOTES:

- 1. Before commencing, remove all wall liners and "D" Rings already installed in the vehicle.
- 2. Consult layout PDF and compare vehicle layout allocated Legend.
- 3. Prepare hardware shown below and have them ready for installation.
- 4. Wall liners will be installed in the order shown in the instructions.
- 5. A drill with a Phillips driver is required to install (**C**) #8 Screws) shown below.
- 6. Reinstall all "D" Rings once the wall liner kit installation is completed.



TRANSIT 148" LOW ROOF WALL LINERS



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	744-114-2613.LR WOW	GREY REAR DRIVER SIDE PANEL LWB LR W\O WINDOW	1
2	744-114-2613.LR WOW	GREY REAR PANEL PASSENGER SIDE W\O WINDOW TRANSIT 148 LR	1
3	744-114-2613.LR WOW	GREY FRONT DRIVER SIDE PANEL W \O WINDOW TRANSIT 148" LR	1
4	RETAINER	RETAINER- BLACK NYLON	117
5	743-114-2613.LR	GREY REAR UPPER DOOR PANEL PASSENGER SIDE TRANSIT 148 LR	1
6	743-114-2613.LR	GREY REAR UPPER DOOR PANEL DRIVER SIDE TRANSIT 148" LR	1
7	745-114-2613.LR	GREY CEILING FRONT PANEL TRANSIT 148" LR	1
8	745-114-2613.LR	GREY CEILING BACK PANEL TRANSIT 148" LR	1
9	747-151-1010.LR	CEILING SILL 2 TRANSIT 148" LR	2
10	747-151-1010.LR	CEILING SILL 1 TRANSIT 148" LR	2
11	747-151-1010.LR	CEILING SILL JOINER PLATE TRANSIT 148" LR	2
12	SCREW	SCREW - PHIL. PAN HD #8X.75 SELF DRILLING	60
13	743-114-2613.LR	GREY SIDE DOOR BOTTOM PANEL TRANSIT 148 LR	1
14	SCREW CAP	SCREW CAP	28
15	743-114-2613.LR	GREY SIDE DOOR TOP PANEL TRANSIT 148 LR	1
16	742-xxx-6641	FLOOR - TRANSIT 148''	1
17	706-151-1011	FLOOR SLIDING DOOR SILL 3 - TRANSIT	1
18	706-151-1011	FLOOR SLIDING SILL 1- TRANSIT	1
19	709-151-1011	FLOOR SLIDING DOOR SILL 2 - TRANSIT	1
20	708-151-1011	FLOOR REAR SILL- TRANSIT	1
21	RETAINER	RETAINER- BLACK NYLON 31163211	12

Hardware and parts will vary depending on the kit purchased; refer to Layout drawings for appropriate hardware and parts.

Driver Side Wall Liner Installation



Back Door Wall Liner Installation









<u>7</u>: Assemble Item 9 and item 10 together with the Item 11, Sill Joining Plate (SHOWN BELOW), with hardware (C) in the holes provided.

- Install the Sill assemblies on the Driver side as well as on the Passenger side using hardware (C) in the holes provided on the Sills.
- First, Install the Sill assembly with hardware (C) on the wall, afterwards install hardware (C) only on the roof cross bows aligned with the retainers holding the ceiling panels.









