



## **Van & Truck Cargo System**

Vantech USA [www.vantech.us](http://www.vantech.us)



### **PRODUCT INFO**

---

Part #: J2203W  
System: J2000  
Material: Aluminum  
Fitment: Ford Transit Connect 2014-On  
Color: White

### **REQUIRED TOOLS**




















---

3/16" Allen Key Wrench




1/2" Wrench




| PART #  | DESCRIPTION                       | QTY | ITEM<br>ITEM NOT DRAWN TO SCALE   |
|---------|-----------------------------------|-----|---|
| S052    | DOUBLE SLIDER 2" BOLT TO BOLT     | 6   |    |
| S062    | DOUBLE SLIDER 1 3/8" BOLT TO BOLT | 2   |    |
| W001    | 1/4" X 3/4" WASHER                | 12  |    |
| W008    | 5/16" X 3/4" WASHER               | 36  |    |
| W022    | 5/16" LOCK WASHER                 | 6   |    |
| B065    | 5/16" X 1" HEX BOLT               | 4   |    |
| B103    | 1/4" X 1" BUTTON HEAD ALLEN BOLT  | 12  |    |
| B068    | 5/16" X 1 3/4" HEX BOLT           | 6   |    |
| N002    | 5/16" NUT                         | 6   |    |
| N005    | 5/16" NYLON NUT                   | 20  |    |
| M11-2   | MOUNTING BASE (LOW)               | 2   |   |
| M11     | MOUNTING BASE (STANDARD)          | 4   |  |
| A285-50 | 2.25" X 1" X 50" CROSS BAR        | 3   |  |
| G203    | RUBBER SEAT 2.75"                 | 6   |  |
| BG550   | RUBBER BAR GUARD 50"              | 3   |  |
| A04     | SIDE SUPPORT                      | 6   |  |
| A11     | LADDER BASE                       | 2   |  |
| A15     | STOPPER                           | 2   |  |
| A69     | EZ-HOOK & LOOP STRAP              | 2   |  |

## Hook & Loop Strap





## Directions





## RUBBER BAR GUARD

- Press the rubber bar guard into the channels of cross bars



## SYSTEM PLACEMENT MUST BE PLACED IN THIS ORDER



Do not tighten hardware

