

PROMASTER 118" WB LOW ROOF WALL LINERS


INSTALLATION INSTRUCTIONS




NOTES:

- 1. Before commencing, remove all wall liners and "D" Rings already installed in the vehicle.
- 2. Consult layout PDF and compare vehicle layout
- 3. Prepare hardware shown below and have them ready for installation.
- 4. Wall liners will be installed in the order shown in the instructions.
- 5. A drill with a Phillips driver is required to install hardware (C) #8 Screws, shown below.
- 6. Reinstall all "D" Rings once the wall liner kit installation is completed.

Hardware



PROMASTER 118" WB LOW ROOF WALL LINERS




ITEM NO.	
1	
2	
3	
4	
5	
6	
5 6 7 8 9	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	
18	


DESCRIPTION	QTY.
GREY REAR WALL PANEL DRIVER SIDE PROMASTER 118" WB LR	1
GREY FRONT WALL PANEL DRIVER SIDE PROMASTER 118" WB LR	1
RETAINER- BLACK NYLON	69
SCREW CAP	26
SCREW - PHIL. PAN HD #8X.75 SELF DRILLING	66
GREY REAR WALL PANEL PASSENGER SIDE PROMASTER 118" WB LR	1
GREY CEILING PANEL PROMASTER 118" WB LR	1
GREY SLIDING DOOR PANEL PROMASTER 118" WB LR	1
GREY REAR DOOR PANEL PASSENGER SIDE PROMASTER 118" WB LR	1
GREY REAR DOOR PANEL DRIVER SIDE PROMASTER 118" WB LR	1
FLOOR - PROMASTER 118" WB	1
CEILING SILL "A" REAR PASSENGER SIDE PROMASTER 118" WB LR	1
CEILING SILL "B" FRONT PASSENGER SIDE PROMASTER 118" WB LR	1
CEILING SILL "C" REAR DRIVER SIDE PROMASTER 118" WB LR	1
CEILING SILL "D" FRONT DRIVER SIDE PROMASTER 118" WB LR	1
REAR DOOR FLOOR SILL PROMASTER	1
SIDE DOOR FLOOR SILL PROMASTER 118" WB	1
JOINER PLATE- CEILING SILL	2

Note:

Model may differ depending if the vehicle purchased came with an OEM partition or not.



Back Door Wall Liner Installation



В, С

<u>ITEM 10</u> REAR DOOR **DRIVERS SIDE PANEL**

3: Install Item 9 and 10, Rear door panels,

<u>Note</u>: Rear doors must be closed when installing door panels.

- Align the panels with the upper door contours, do not mount tight against the door seals.
- Install hardware (A) first in the holes provided, this will align the panel then install hardware (B, C) on the top of the panel first, working your way down the panel to the bottom.



Α

