




## SPRINTER 144" WB LOW ROOF WALL LINERS

### INSTALLATION INSTRUCTIONS




#### NOTES:

1. Before commencing, remove all wall liners and "D" Rings already installed in the vehicle.
2. Consult layout PDF and compare vehicle layout
3. Prepare hardware shown below and have them ready for installation.
4. Wall liners will be installed in the order shown in the instructions.
5. A drill with a Phillips driver is required to install hardware ( **C** ) #8 Screws, shown below.
6. Reinstall all "D" Rings once the wall liner kit installation is completed.



# SPRINTER 144" WB LOW ROOF WALL LINERS



ITEM NO.	DESCRIPTION	QTY.
1	GREY REAR DRIVER SIDE PANEL SPRINTER 144" WB LR	1
2	GREY REAR PASSENGER SIDE PANEL SPRINTER 144 WB LR	1
3	GREY CEILING PANEL FRONT SPRINTER 144" WB LR	1
4	GREY CEILING PANEL REAR SPRINTER 144" WB LR	1
5	GREY FRONT DRIVER SIDE PANEL SPRINTER 144" WB LR	1
6	CEILING SILL C SPRINTER 144" WB LR	1
7	CEILING SILL C-1 SPRINTER 144 WB LR	1
8	CEILING SILL D SPRINTER 144" WB LR	1
9	CEILING SILL A SPRINTER 144 WB LR	1
10	CEILING SILL B SPRINTER 144 WB LR	1
11	CEILING SILL A-1 SPRINTER 144 WB LR	1
12	CEILING SILL B-1 SPRINTER 144 WB LR	1
13	FLOOR - SPRINTER 144"	1
14	SILL - FLOOR- REAR - SPRINTER	1
15	SILL - FLOOR - SIDE DOOR - SPRINTER	1
16	SCREW - PHIL. PAN HD #8X.75 SELF DRILLING	108
17	JOINER PLATE - SILLS - SPRINTER LR	4
18	GREY TOP DOOR PANEL SLIDING GOOR SPRINTER LR	1
19	GREY BOTTOM PANEL SLIDING DOOR SPRINTER LR	1
20	RETAINER- BLACK NYLON	88
21	SCREW CAP	52
22	GREY REAR DOOR PANEL PASSENGER SIDE SPRINTER LR	1
23	GREY REAR DOOR PANEL DRIVER SIDE SPRINTER LR	1

Note:

Model may differ depending if the vehicle purchased came with an OEM partition or not.



## Driver Side Wall Liner Installation

ITEM 5  
FRONT  
DRIVERS SIDE  
PANEL


ITEM 1  
REAR DRIVERS  
SIDE PANEL

FRONT

REAR



A



B, C

**Note:** If a rear view camera option is installed, break and bend downwards at the scored lines at the top section of both panels so it fits under the plastic tubing. It can also be cut off if desired.

**1:** Install Item 5, Front Driver Side Panel.

- Align notch and edge of panel with the feature on the vehicle driver side front then align opposite side of panel edge with the contour features.

- Install hardware (A) and (B,C), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.


**2:** Install Item 1, Rear Driver Side Panels.

- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.

- Install hardware (A) and (B,C), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.


**NOTE: DO NOT INSTALL HARDWARE IN THE HOLES AT THE TOP OF THE PANELS, THESE ARE USED FOR THE SILL INTALLATION**

Installation completed




## Back Door Wall Liner Installation

ITEM 22  
REAR DOOR  
PASSENGER SIDE  
PANEL



ITEM 23  
REAR DOOR  
DRIVERS SIDE  
PANEL




B, C

**3:** Install Item 22 and 23, Rear door panels,

**Note:** Rear doors must be closed when installing door panels.




- Align the panels with the door contour; **do not mount tight against the door seals.**
- Install hardware (B, C) on the bottom of the panel first, working your way up the panel to the top.

Installation completed





## Passenger Side Wall Liner Installation



**NOTE: DO NOT INSTALL HARDWARE IN THE HOLES AT THE TOP OF THE PANELS; THESE ARE USED FOR THE SILL INTALLATION.**

**\*FOR ITEM 18, TOP SLIDING DOOR PANEL, ALIGN HOLES IN THE PANEL TO THE RIBS OF THE DOOR TO ENSURE PROPER SCREW INSTALLATION.**

**4:** Install Item 2, Rear Passenger Side Panel.

- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top. Install hardware (B, C) in the holes provided in the middle to the top part of the panel

**5:** Install Item 18, 19, Sliding Door Panel.

First remove OEM bottom panel.  
Note: Sliding door must be closed to install panel;

- Insert panel into the sliding door sill cavity, align holes at the bottom panel to the one on the door and insert hardware (A) in all of the holes provided.
- Install hardware (B, C) in the holes provided in the top panel; make sure the panel does not interfere with the door seal.

**Installation completed**

