




TRANSIT 148" EXTENDED HIGH ROOF WALL LINERS

INSTALLATION INSTRUCTIONS




NOTES:

1. Before commencing, remove all wall liners and "D" Rings already installed in the vehicle.
2. Consult layout PDF and compare vehicle layout
3. Prepare hardware shown below and have them ready for installation.
4. Wall liners will be installed in the order shown in the instructions.
5. A drill with a Phillips driver is required to install (C) #8 Screws, shown below.
6. Reinstall all "D" Rings once the wall liner kit installation is completed.



TRANSIT 148" EXT. HIGH ROOF WALL LINERS



ITEM NO.	DESCRIPTION	QTY.
1	GREY CEILING FRONT PANEL TRANSIT 148" EXT HR	1
2	GREY CEILING BACK PANEL TRANSIT 148" EXT HR	1
3	RETAINER- BLACK NYLON	158
4	CEILING SILL A TRANSIT 148" EXT HR	1
5	CEILING SILL C TRANSIT 148" EXT HR	1
6	CEILING SILL B TRANSIT 148" EXT HR	1
7	CEILING SILL D TRANSIT 148" EXT HR	1
8	SCREW - PHIL. PAN HD #8X.75 SELF DRILLING	76
9	CEILING SILL JOINER PLATE TRANSIT 148" EXT HR	2
10	GREY REAR UPPER DOOR PANEL PASSENGER SIDE TRANSIT 148" EXT HR	1
11	GREY REAR UPPER DOOR PANEL DRIVER SIDE TRANSIT 148" EXT HR	1
12	SCREW CAP	34
13	GREY REAR PANEL DRIVER SIDE TRANSIT 148" EXT HR	1
14	GREY REAR UPPER DRIVER SIDE PANEL TRANSIT 148" EXT HR	1
15	GREY REAR PANEL PASSENGER SIDE TRANSIT 148" EXT HR	1
16	FLOOR TRANSIT 148" EXT. HR	1
17	RETAINER- BLACK NYLON 31163211	12
18	FLOOR REAR SILL- TRANSIT	1
19	FLOOR SLIDING DOOR SILL 3 - TRANSIT	1
20	FLOOR SLIDING SILL 1- TRANSIT	1
21	FLOOR SLIDING DOOR SILL 2 - TRANSIT	1
22	GREY SIDE DOOR TOP PANEL TRANSIT 148" EXT HR	1
23	GREY SIDE DOOR BOTTOM PANEL TRANSIT 148" EXT HR	1
24	GREY FRONT PANEL DRIVER SIDE TRANSIT 148" EXT HR	1
25	GREY FRONT UPPER DRIVER SIDE PANEL TRANSIT 148" EXT HR	1
26	GREY FRONT UPPER PASSENGER SIDE PANEL TRANSIT 148" EXT HR	1

Driver Side Wall Liner Installation

ITEM 14
REAR UPPER DRIVERS SIDE PANEL


ITEM 13
REAR DRIVERS SIDE PANEL

ITEM 25
FRONT UPPER DRIVERS SIDE PANEL

ITEM 24
FRONT
DRIVERS SIDE
PANEL

REAR

FRONT




1: Install Item 24 and 25, Front Driver Side Panels.

- Align notch and edge of panel with the feature on the vehicle driver side front then align opposite side of panel edge with the contour features.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.

2: Install Item 13 and 14, Rear Driver Side Panels.


- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.

Installation completed




Back Door Wall Liner Installation

ITEM 10
UPPER REAR
DOOR PASSENGER
SIDE PANEL




ITEM 11
UPPER REAR
DOOR DRIVERS
SIDE PANEL




3: Install Item 10 and 11, Upper door panels,

- Align the Upper panels with the upper door contours.
- Install hardware (B, C), in the holes provided, on the top of the panel first, working your way down the panel to the bottom.


Installation completed




Passenger Side Wall Liner Installation



ITEM 23
SLIDING DOOR
BOTTOM PANEL



Installation completed



- 4:** Install Item 15, Rear Passenger Side Panel.
- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.
 - Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.
 - Install Item 26, Upper Sliding Door Panel.
 - Install hardware (A), in the holes provided.

- 5:** Install Item 23, Bottom Sliding Door Panel. First remove OEM bottom panel.
- Note: Sliding door must be closed to install panel;
- Insert panel into the sliding door sill cavity, align holes at the bottom half of the panel to the one on the door and insert hardware (A) in all of the holes.
 - Install Item 22, Top Sliding Door Panel with hardware (B, C) in the holes provided; align the panel with the door seal leaving an equal space between the door seal and the panel.