





TRANSIT 148" HIGH ROOF WALL LINERS INSTALLATION INSTRUCTIONS

NOTES:

1. Before commencing, remove all wall liners and "D" Rings already installed in the vehicle.
2. Consult layout PDF and compare vehicle layout
3. Prepare hardware shown below and have them ready for installation.
4. Wall liners will be installed in the order shown in the instructions.
5. A drill with a Phillips driver is required to install (C) #8 Screws, shown below.
6. Reinstall all "D" Rings once the wall liner kit installation is completed.



TRANSIT 148" HIGH ROOF WALL LINERS




ITEM NO.	DESCRIPTION	QTY.
1	GREY REAR PANEL DRIVER SIDE TRANSIT 148" HR	1
2	GREY FRONT PANEL DRIVER SIDE TRANSIT 148 HR	1
3	GREY REAR PANEL PASSENGER SIDE TRANSIT 148" HR	1
4	GREY REAR UPPER DRIVER SIDE PANEL TRANSIT 148 HR	1
5	GREY FRONT UPPER DRIVER SIDE PANEL TRANSIT 148 HR	1
6	GREY FRONT UPPER PASSENGER SIDE PANEL TRANSIT 148 HR	1
7	RETAINER- BLACK NYLON	127
8	GREY CEILING FRONT PANEL TRANSIT 148" HR	1
9	GREY CEILING BACK PANEL TRANSIT 148" HR	1
10	SCREW - PHIL. PAN HD #8X.75 SELF DRILLING	70
11	GREY REAR UPPER DOOR PANEL PASSENGER SIDE TRANSIT 148 HR	1
12	GREY REAR UPPER DOOR PANEL DRIVER SIDE TRANSIT 148 HR	1
13	SCREW CAP	34
14	FLOOR - TRANSIT 148"	1
15	FLOOR REAR SILL- TRANSIT	1
16	FLOOR SLIDING DOOR SILL 3 - TRANSIT	1
17	FLOOR SLIDING SILL 1- TRANSIT	1
18	FLOOR SLIDING DOOR SILL 2 - TRANSIT	1
19	RETAINER- BLACK NYLON 311 63211	12
20	GREY SIDE DOOR TOP PANEL TRANSIT 148" HR	1
21	GREY SIDE DOOR BOTTOM PANEL TRANSIT 148 HR	1
22	CEILING SILL 2 TRANSIT 148" HR	2
23	CEILING SILL 1 TRANSIT 148" HR	2
24	CEILING SILL JOINER PLATE	2

Driver Side Wall Liner Installation


ITEM 4
REAR UPPER DRIVERS SIDE PANEL

ITEM 5
FRONT UPPER DRIVERS SIDE PANEL

ITEM 2
FRONT
DRIVERS SIDE
PANEL



ITEM 1
REAR DRIVERS SIDE PANEL




1: Install Item 2 and 5, Front Driver Side Panel.

- Align notch and edge of panel with the feature on the vehicle driver side front then align opposite side of panel edge with the contour features.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.

2: Install Item 1 and 4, Rear Driver Side Panel.

- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.


Installation completed



Back Door Wall Liner Installation


ITEM 11

UPPER REAR
DOOR PASSENGER
SIDE PANEL



ITEM 12

UPPER REAR
DOOR DRIVERS
SIDE PANEL




B, C



3: Install Item 11 and 12, Upper door panels,

- Align the Upper panels with the upper door contours.
- Install hardware (B, C), in the holes provided, on the top of the panel first, working your way down the panel to the bottom.


Installation completed



Passenger Side Wall Liner Installation



Installation completed



4: Install Item 3, Rear Passenger Side Panel.

- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.
- Install Item 6, Upper Sliding Door Panel.
- Install hardware (A), in the holes provided.

5: Install Item 21, Bottom Sliding Door Panel.

First remove OEM bottom panel.

- Note: Sliding door must be closed to install panel;
- Insert panel into the sliding door sill cavity, align holes at the bottom half of the panel to the one on the door and insert hardware (A) in all of the holes.
- Install Item 20, Top Sliding Door Panel with hardware (B, C) in the holes provided; align the panel with the door seal leaving an equal space between the door seal and the panel.