




TRANSIT 148" LOW ROOF WALL LINER

INSTALLATION INSTRUCTIONS




NOTES:

1. Before commencing, remove all wall liners and "D" Rings already installed in the vehicle.
2. Consult layout PDF and compare vehicle layout
3. Prepare hardware shown below and have them ready for installation.
4. Wall liners will be installed in the order shown in the instructions.
5. A drill with a Phillips driver is required to install (**C**) #8 Screws) shown below.
6. Reinstall all "D" Rings once the wall liner kit installation is completed.



TRANSIT 148" LOW ROOF WALL LINERS



ITEM NO.	DESCRIPTION	QTY.
1	GREY REAR DRIVER SIDE PANEL LWB LR W\O WINDOW	1
2	GREY REAR PANEL PASSENGER SIDE W\O WINDOW TRANSIT 148 LR	1
3	GREY FRONT DRIVER SIDE PANEL W \O WINDOW TRANSIT 148" LR	1
4	RETAINER- BLACK NYLON	117
5	GREY REAR UPPER DOOR PANEL PASSENGER SIDE TRANSIT 148 LR	1
6	GREY REAR UPPER DOOR PANEL DRIVER SIDE TRANSIT 148" LR	1
7	GREY CEILING FRONT PANEL TRANSIT 148" LR	1
8	GREY CEILING BACK PANEL TRANSIT 148" LR	1
9	CEILING SILL 2 TRANSIT 148" LR	2
10	CEILING SILL 1 TRANSIT 148" LR	2
11	CEILING SILL JOINER PLATE TRANSIT 148" LR	2
12	SCREW - PHIL. PAN HD #8X.75 SELF DRILLING	60
13	GREY SIDE DOOR BOTTOM PANEL TRANSIT 148 LR	1
14	SCREW CAP	28
15	GREY SIDE DOOR TOP PANEL TRANSIT 148 LR	1
16	FLOOR - TRANSIT 148"	1
17	FLOOR SLIDING DOOR SILL 3 - TRANSIT	1
18	FLOOR SLIDING SILL 1- TRANSIT	1
19	FLOOR SLIDING DOOR SILL 2 - TRANSIT	1
20	FLOOR REAR SILL- TRANSIT	1
21	RETAINER- BLACK NYLON 31163211	12

Hardware and parts will vary depending on the kit purchased; refer to Layout drawings for appropriate hardware and parts.


Driver Side Wall Liner Installation

ITEM 1
REAR DRIVERS
SIDE PANEL

FRONT

REAR

ITEM 3
FRONT
DRIVERS
SIDE PANEL



A


1: Install Item 3, Front Driver Side Panel.

- Align notch and edge of panel with the feature on the vehicle driver side front then align opposite side of panel edge with the contour features.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.

2: Install Item 1, Rear Driver Side Panel.

- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.



Installation completed



Back Door Wall Liner Installation

ITEM 5
UPPER DOOR
PASSENGER SIDE
PANEL


ITEM 6
UPPER DOOR
DRIVERS SIDE
PANEL



3: Install Item 5 and 6, Upper door panels,

- Align the Upper panels with the upper door contours as well as with the door lock opening.
- Install hardware (B, C), in the holes provided, on the top of the panel first, working your way down the panel to the bottom.

Installation completed



Passenger Side Wall Liner Installation

ITEM 15
SLIDING DOOR
TOP PANEL

FRONT

B, C


A

REAR

A

ITEM 13
SLIDING DOOR
BOTTOM PANEL

ITEM 2
REAR PASSENGER
SIDE PANEL



4: Install Item 2, Rear Passenger Side Panel.

- Align wheel well edge of the panel with the feature on the vehicle; position the contour of the panel to the vehicle wall.
- Install hardware (A), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.

5: Install Item 13, Bottom Sliding Door Panel.

Note: Sliding door must be closed to install panel;
First remove OEM bottom panel.

- Insert panel into the sliding door sill cavity, align holes at the bottom half of the panel to the one on the door and insert hardware (A) in all of the holes.
- Install Item 15, Top Sliding Door Panel with hardware (B, C) in the holes provided, align the panel with the door seal leaving an equal space between the door seal and the panel, and make sure the door lock opening is aligned with the door lock.

Installation completed

